



FIGYELEM!

Gyári gumirugó előkészítés beállítási utasítás:

A 612-es szabványával egyetemben kell a gumirugókat előkészíteni, hogy az anyó külső homloklapjait, és a 212-es rugóház 512-es vezérlőlapjára felfekvő homloklapjait között a távolság 50 mm legyen. A 312-es bekötőszem orsóinak a rugóházba való behelyezése és a 11-es és 18-as távtartócső alátét felhelyezése után a 17-es hengeres anyóval a bekötőszem orsó részének feltétlenül kinyomása szükséges. Ez max. 1 mm-es tengelyirányú elmozdulást lehet elérni: a gumirugó külső átmérő és rugóház között. Beállítások után a 912-es csavart meg kell húzni, és a 4312-es valamint a 412-es hengeres csavart be kell szerelni. Az xxx-xx jelű felületeket az összeszerelés során gondosan kell hermetizálni kénia rugós bekötés vízszigetelésén.

A 412-es csavarok M20-es menetű fúratokat szerelőkör fúrnak!

A rugós bekötés 3 és 112-es távtartócsőnek 12018 méretű csúszó felületeit az összeszerelés során gondosan be kell kenni molybdén-diszulfidos zsírral!

ATTENTION!

Adjustment instructions for prestressing the rubber spring by the manufacturer:

Prestress the rubber spring by the clamping nut of Pos. No. 6 in such a way that the distance between the outer face of the nut and the bearing front face of the spring case of Pos. No. 2, bearing on the guide disc of Pos. No. 5, be 50 mm. After placing the spindle of the connecting lug of Pos. No. 3 in the spring case and mounting the distance pipes of Pos. Nos. 11 and 18 and the washer, set the cylindrical nut of Pos. No. 17 so as to unconditionally eliminate any clearance of the spindle part of the connecting lug.

A further prestressing of not more than 1 mm by the nut is permissible. This will enable an axial displacement of not exceeding 1 mm between the outer diameter of the rubber spring and the spring case. After adjusting, tighten the screw of Pos. No. 9 and mount the grub screws of Pos. Nos. 43 and 41 in order to ensure watertightness of the spring attachment, carefully smear the surfaces marked with Hermetic during assembly.

Drill the M20 threaded holes of bolts of Pos. No. 41 on mounting! Carefully lubricate the sliding surfaces of size dia. 12018 of the components of Pos. Nos. 3 and 11 of the spring attachment with molybdenum-disulfide grease during assembly!

47	Li. csavar	M5x15	MSz 2437	36	0,002	0,028	
46	Rugós alátét	M8	MSz 2210	C45	0,009	0,054	
45	Hi. fm. csavar	M8x20	MSz 2363	3,6	0,016	0,084	
44	Csapos hengeres csavar II.	M12x35	MSz 2423	5,6	0,022	0,044	legyártani!
43	Hengeres csavar II.	M10x30	MSz 2422	5,6	0,014	0,042	to be manufactured!
42	Rugós alátét	M20	MSz 2210	C45	0,014	0,056	
41	Hi. fm. csavar	M20x40	MSz 2363	3,6	0,15	0,60	
40	Hi. anya	M16	MSz 2161	5	0,03	0,24	
39	Hi. csavar	M16x120	MSz 2360	3,6	0,21	1,68	
38	Hi. anya	M30	MSz 2161	5	0,22	2,64	
37	Hi. csavar	M30x130	MSz 2360	3,6	0,95	7,4	
36	Zsírzsárlépcső 100	M16x15	MSz 374/5		0,16	0,32	
35	Zsírzsárlépcső 50	M14x15	MSz 374/5			0,09	
34	Bedőlő rádiális csap	23128 C	MSz 7231			10,3	
33	Arched stop plate	CD-14-27041				0,07	
32	Bedőlő tárcsa	146-32-212-34161				1,06	
31	Bedőlő tárcsa	146-32-212-34160				1,0	
30	Tengelyfogó 4	CD-14-17704/02				0,089	
29	Biztosítóleme	CD-14-2036/01			0,035	0,42	
28	Biztosítóleme	CD-14-2035/01			0,025	0,2	
27	Csőfengely	146-32-212-34159				4,16	
26	Rövid tengelyfogó 13	CD-14-17713/02			0,76	1,52	
25	Csap	146-32-212-34158				25,82	
24	Távtartócső	146-32-212-34157				0,86	
23	Távtartócső	146-32-212-34156				0,86	
22	Csatlakozó darab	D1050-525-44-8032/02				0,08	
21	Fedél	146-32-212-34155				3,9	
20	Fedél	146-32-212-34154				3,9	
19	Zsírzsárlépcső	D1050-212-14-20338/02				0,8	
18	Alátét	D1050-212-14-20337/01				1,78	
17	Hengeres anya	D1050-212-13-1850/03				7,3	
16	Gumiburkolat	D1050-212-14-18010				0,5	
15	Szorító gyűrű	D1050-212-14-18009/01				0,35	
14	Perem	D1050-212-14-18008/01				0,65	
13	Karima	D1050-212-14-18007/01				1,5	
12	Zsírzsárlépcső	D1050-212-14-20336/01				0,3	
11	Távtartócső	D1050-212-14-20335/02				9,7	
10	Bedőlőleme	D1050-212-14-20334/01			14	12,6	
9	Hi. rugós csavar	D1050-212-14-20333/01				0,75	
8	Támasztó	D1050-212-14-20332/02				16,4	
7	Támasztó	D1050-212-14-20331/02				16,4	
6	Szorító anya	D1050-212-14-20330/02				26,5	
5	Vezető tárcsa	D1050-212-12-20329/03				50,-	
4	Gumirugó	D1050-212-12-20328			3,5	35,-	
3	Bekötőszem	146-32-212-34153				715,-	
2	Rugóház	D1050-212-12-20327/02				279,5	
1	Fogas/éc	146-32-200-34152				1213,67	

1:25	1859,8	358-3	146-32-212-34151
Gébillentyű	kg.		
Rugós bekötés			
Spring Attachment			
1986. 03. 19.			
Dr. T. I.			
Dan. osztály			